

Naturally Aged Flooring

Floating Floor Installation Instructions

- 1. It is recommended to install the planks parallel to the longest wall.***
- 2. Using spacers to maintain the expansion space, begin by laying the first plank in a corner with the long grooved side toward the long wall.***
- 3. Apply a small continuous consistent bead of Titebond T&G flooring glue along the bottom side of the groove.***
- 4. Connect the short side of the second plank together with the mating side of the first plank.***
- 5. Cut the last plank and complete the row. Use the remaining plank to start the second row.***
- 6. Be sure to offset the end joins of consecutive rows by a minimum of six inches for best appearance.***
- 7. Continue the second row by connecting the short edges of the planks first with the long edges.***
- 8. The last row may require rip cutting the planks to size.***
- 9. Cut enough to create the expansion space.***
- 10. As with the other rows, connect the short edges first and use a pull bar to tap the long edges together.***